

Enjoy **MOVIE** Time,
ANYTIME...

Day



or Night!



- ✓ Free Movies
- ✓ NEW Releases
- ✓ Movies starting at \$2.99
- ✓ Choose from Action, Thriller, Drama and Family

Choose from
a huge library of movies.

To Watch a FREE Movie,
arrow over and select WATCH.

To Rent a Movie,

Select the movie, use arrows to select
RENT, Enter the Purchase Pin.

You may need to add a monthly allowance
to your account to rent other movies.

Default Purchase Pin number is 0000.

Pin number can be change by going
to Menu; Settings; Parental; Change
Pin Studios do not allow VOD movies
to be recorded.

Must subscribe to RC Technologies
TV to receive Video On Demand



RC Technologies

205 Main St | PO Box 197

New Effington, SD 57255

www.tnics.com

605.637.5211

Remote Control Guide



Controlling The Remote

TV, AUD, DVD, VCR, STB
Use one remote to control multiple devices.

Setup
Use for programming sequences of devices controlled by the remote.

Skip Forward, Skip Back, REW, PLAY, FFWD, STOP, Pause, Record
In STB mode, these control the DVR functions. In other modes, these can control a VCR, DVD Player or PVR.

Menu
Displays the menu.

Guide
Opens the Interactive Program Guide.

Day +/-
Jump ahead or back one day in the Interactive Program Guide.

Red, Green, Yellow, Blue
Access additional features on your set-top box.

Vol +/-
Raise or lower the volume.

Mute
Turn the sound off or on.

Aspect Ratio *
Temporarily change the conversion mode from Original Size or Fit to Screen.

Input
In TV control mode, will change the input of the device you are controlling.

Power
Turn on/off a selected device.

Live
Return to watching live TV.

List
Display a list of recorded, future and series rules on your DVR.

Info
Display the current channel and program information. Press again for more detail.

Browse, Search, Arrow and OK
Navigate and select onscreen choices.

Exit
Exit the current screen.

Page +/-
Page up or down in lists and Interactive Program Guide.

Channel +/-
Changes to the next higher or lower channel.

On Demand
Access video on demand services.

Last
Recall the last channel you were watching.

FAV
View your favorite channels.

Number Keys (0-9)
Directly select a channel or enter options.

Button
Use to turn closed captioning on and off.



WHAT'S ON TV?

There's more than one way to see what's showing on TV.

Info Button:

Press Info and you will see the name and a description of the current program at the top of the screen.

OK Button:

Press OK to show the 'Now Playing' bar and you will see what program is currently playing.

Guide Button:

This is the most comprehensive view of what's on. Go ahead and page through...you're bound to find something to watch.

Browse Button:

Press Browse (right arrow) to show the channel you are currently tuned to at the top of the screen. At the bottom of the screen, the 'Info Bar' shows you the channel number, channel name, current date and time, program name, date and time the program airs, a progress bar, and the program that airs next.

*If Available